

CANDY *SmartPro*




SMART PRO

1



2



3



4



5



41049336



To download any other further information in your language, please go to:

go.candy-group.com/sm



simply | Fi

Download the
Candy simply-Fi App





Download on the
App Store

ANDROID APP ON
Google play



LANGUAGE




PROGRAMS






















4

OPTIONS



3



	kg (MAX.)							°C MAX				
	6 +4 kg	7 +5 kg	8 +5 kg	8 +6 kg	9 +5 kg	9 +6 kg	10 +6 kg		2		1	
	6	7	8	8	9	9	10	90°	•	•	•	
	6	7	8	8	9	9	10	60°	•	•		
	1	1	2	2	2	2	2	30°	•	•		
	2	2	2	2	2	2	2	60°	•	•		
	-	-	-	-	-	-	-	-	△			
	-	-	-	-	-	-	-	-				
	1	1	1	1	1	1	1	-				
	59'	3	3,5	4	4	4,5	4,5	5	-			
	39'	4	5	5	6	5	6	6	-			
	59'	1	1	1,5	1,5	1,5	1,5	1,5	40°	•	•	
	14'	1	1	1,5	1,5	1,5	1,5	1,5	30°	•	•	
	30'	2	2,5	2,5	2,5	2,5	2,5	2,5	30°	•	•	
	44'	3	3,5	3,5	3,5	3,5	3,5	3,5	40°	•	•	
	59'	6	7	8	8	9	9	10	40°	•	•	
	59'	3	3,5	4	4	4,5	4,5	5	40°	•	•	
	49'	6	7	8	8	9	9	10	40°	•	•	
	WI-FI											



1 

Download the **Candy Simply-Fi App**





Download on the **App Store**


ANDROID APP ON **Google play**

2 





3 





4 




5 




6 




7



8



9





10  "Only 2.4 GHz frequency band supported"



11  **CONNECTED** ✓

Remote Control

A 

B 

C 